



# USER MANUAL

## AMPAQ-PWM Amplifier

Set Up and Configuration



© 2016 Quanser Inc., All rights reserved.

Quanser Inc.  
119 Spy Court  
Markham, Ontario  
L3R 5H6  
Canada  
info@quanser.com  
Phone: 1-905-940-3575  
Fax: 1-905-940-3576

Printed in Markham, Ontario.

For more information on the solutions Quanser Inc. offers, please visit the web site at:  
<http://www.quanser.com>

This document and the software described in it are provided subject to a license agreement. Neither the software nor this document may be used or copied except as specified under the terms of that license agreement. All rights are reserved and no part may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Quanser Inc.

#### Waste Electrical and Electronic Equipment (WEEE)



This symbol indicates that waste products must be disposed of separately from municipal household waste, according to Directive 2002/96/EC of the European Parliament and the Council on waste electrical and electronic equipment (WEEE). All products at the end of their life cycle must be sent to a WEEE collection and recycling center. Proper WEEE disposal reduces the environmental impact and the risk to human health due to potentially hazardous substances used in such equipment. Your cooperation in proper WEEE disposal will contribute to the effective usage of natural resources. For information about the available collection and recycling scheme in a particular country, go to [ni.com/citizenship/weee](http://ni.com/citizenship/weee).

#### 电子信息产品污染控制管理办法（中国 RoHS）



中国客户 National Instruments 符合中国电子信息产品中限制使用某些有害物质命令（RoHS）。  
关于National Instruments 中国 RoHS合规性信息，请登录 [ni.com/environment/rohs\\_china](http://ni.com/environment/rohs_china)  
(For information about China RoHS compliance, go to [ni.com/environment/rohs\\_china](http://ni.com/environment/rohs_china))

#### CE Compliance

This product meets the essential requirements of applicable European Directives as follows:

- 2006/95/EC; Low-Voltage Directive (safety)
- 2004/108/EC; Electromagnetic Compatibility Directive (EMC)

#### FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### Industry Canada Notice

This Class A digital apparatus complies with Canadian ICES-003.  
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

# CONTENTS

<b>1</b>	<b>Presentation</b>	<b>4</b>
1.1	Description	4
<b>2</b>	<b>Components</b>	<b>5</b>
<b>3</b>	<b>Specifications</b>	<b>7</b>
<b>4</b>	<b>Fuse Installation</b>	<b>8</b>
<b>5</b>	<b>Wiring Procedure</b>	<b>10</b>
5.1	Cable Nomenclature	10
5.2	Typical Connections	11
<b>6</b>	<b>Troubleshooting</b>	<b>12</b>
<b>7</b>	<b>Technical Support</b>	<b>12</b>

# 1 PRESENTATION

## 1.1 Description

The Quanser AMPAQ-PWM, pictured in Figure 1.1, is a pulse width modulated (PWM) current amplifier designed to power Quanser experiments. The AMPAQ-PWM is a single channel amplifier, meaning it can power a single load. The AMPAQ-PWM replaces the UPM line of power amplifiers with additional benefits, including a generic data acquisition board (DAQ) interface for increased flexibility, current sensing capability, and an auxiliary E-Stop connector to allow a single E-Stop button to stop multiple devices.



Figure 1.1: Quanser AMPAQ-PWM



**Caution:** This equipment is designed to be used for educational and research purposes and is not intended for use by the general public. The user is responsible to ensure that the equipment will be used by technically qualified personnel only.



**Caution:** If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

## 2 COMPONENTS

The components on the front and back panels of the AMPAQ-PWM are depicted in Figure 2.1. Each component on the AMPAQ has an identification number that corresponds to a short description given in Table 2.1. The pin out information for the analog sensor's mini-DIN connectors and the 16-pin digital I/O connector header are shown in Figure 2.2.

ID	Name	Description	Electrical Range
1	<i>Amplifier Command</i> connector	The input command signal from the DAQ is a voltage that controls the output current. The AMPAQ-PWM adjusts the output duty cycle to maintain the commanded output current.	$\pm 10$ V
2	<i>Current Sense</i> connector	This connector provides a voltage proportional to the actual output current. Scaling is 1 Volt = 2.1 Amps. The AMPAQ-PWM must be connected to a load in order for the <i>Current Sense</i> connector to output a voltage.	
3	<i>Status</i> LED	Indicates if the amplifier is powered up, as well as the status of the amplifier. When the amplifier is powered up but disabled, the LED turns red. When the amplifier is powered up and enabled, the LED turns green.	
4	<i>To Load</i> connector	This connector provides power to the load. The output current is controlled by the <i>Amplifier Command</i> signal.	3.75 A Cont., 15 A Peak
5	<i>Calibrate</i> LED	Indicates the calibration status of the connected device (i.e. Shake Table II).	
6	<i>E-Stop</i> connector	The AMPAQ-PWM requires an E-Stop (emergency stop) button to be connected. If no E-Stop button is connected, the AMPAQ-PWM is disabled by default.	
7	<i>Auxiliary E-Stop</i> connector	Connector for an additional E-Stop to enable daisy-chaining stop commands to multiple devices.	
8	<i>From Device</i> connector	Carries the sensor I/O from the device including encoder signals, limit switch states, etc.	
9	<i>Limit Switch</i> LEDs	Indicate the status of the limit switches on the connected device	
10	<i>Encoder</i> Output connector	Connector to output the device encoder signal to an external DAQ device	
11	<i>Digital I/O</i> Output connector	Connector to output the digital signals from the device sensors to an external DAQ device	Low:0-0.8 V, High:2-5.5 V
12	<i>S1-S4</i> Analog Sensor Output connectors	Used to send the analog sensor signals from the connected device to an external DAQ	
13	<i>S1-S4</i> Analog Sensor Input connectors	Used to properly power the analog sensors on the connected device	$\pm 12$ V
14	Fuses	Replaceable fuses to protect the amplifier	
15	Power switch	Amplifier power switch	
16	Power connector	Used to connect the amplifier to the mains	

Table 2.1: AMPAQ-PWM components



**Caution:** Do not exceed the maximum PWM *Load* ratings 3.75 A continuous, 15 A peak, and 240 VAC.



**Caution:** Do not replace the power cable provided with one of lower quality or rating.



(a) Front



(b) Back

Figure 2.1: AMPAQ-PWM components




Figure 2.2: AMPAQ-PWM analog and digital sensor connectors

# 3 SPECIFICATIONS

Table 3.1 lists the AC input requirements for the AMPAQ-PWM. The PWM output specifications are given in Table 3.2, and the general amplifier specifications are listed in Table 3.3.

AC Input Specifications	Value
Input Voltage Range	100 VAC - 120 VAC or 200 VAC - 240 VAC
Input Frequency Range	50 Hz - 60 Hz
AC Current Rating	3.75 A
Fuses	3.5 A, 250 V, 3AG Slow Blow
Protection Class	Class I

Table 3.1: AC Input Specifications

PWM Output Specifications	Value
Maximum Continuous Output Current	3.75 A
Maximum Peak Output Current (Maximum duration approximately 2 seconds.)	15 A
Maximum Output Voltage (Output voltage is dependent on the input voltage.)	240 VAC
Switching Frequency	20 kHz

Table 3.2: PWM Output Specifications



**Caution:** Do not exceed the maximum PWM load ratings of 3.75 A continuous, 15 A peak, and 240 VAC.

Amplifier Specifications	Value
Amplifier Command Input	$\pm 10$ V
Current Sense Output	1 V = 2.1 A
Digital Inputs	Low-level: 0 V - 0.8 V High-level: 2.0 V - 5.5 V
Digital Outputs	Low-level: 0 V - 0.6 V High-level: 4.1 V - 5.2 V
Mass	10.4 kg
Dimensions	0.39 m $\times$ 0.39 m $\times$ 0.14 m
Environmental	<ul style="list-style-type: none"> <li>• Standard rating</li> <li>• Indoor use only</li> <li>• Altitude up to 2000m</li> <li>• Maximum relative humidity of 80% up to 31°C decreasing linearly to 50% relative humidity at 40°C</li> <li>• Pollution Degree 2</li> <li>• Mains supply voltage fluctuations up to <math>\pm 10\%</math> of the nominal voltage</li> <li>• Maximum transient overvoltage 2500V</li> <li>• Marked degree of protection to IEC 60529: Ordinary Equipment (IPX0)</li> </ul>

Table 3.3: Amplifier Specifications



**Caution:** Precaution must be taken during the connection of this equipment to the AC outlet to make sure the grounding (earthing) is in place and the ground wire is not disconnected.



**Caution:** Avoid covering the fan during operation to prevent premature thermal shutdown of the amplifier.



**Caution:** Do not position the equipment so that it is difficult to operate the on/off switch.



**Caution:** The AMPAQ-PWM devices are made to be used with Quanser designed experiment kits that have particular actuators. Use caution if the AMPAQ-PWM is being used with your own actuator. Any load to be used with the AMPAQ-PWM should have a minimum inductance of 0.1 mH.



**Caution:** Do not use the cables provided with the AMPAQ-PWM to wire it to experiments that use a different amplifier module. The AMPAQ-PWM can be used with such experiments only if plant specific cables are available.

## 4 FUSE INSTALLATION

The AMPAQ-PWM has two 3.5 Amp fuses that protect the amplifier from overcurrent through the main power connector. If you find your unit does not output power from the *To Load* connector, or otherwise stops functioning, check the fuses.



**Caution: Make sure the power to the amplifier is disconnected before changing any fuses!**

Follow this procedure to install or replace the fuses in the AMPAQ-PWM:



1. The fuse holders are located at the rear of the unit, shown in Figure 2.1 with ID #14.
2. Make sure the amplifier power cable is disconnected.
3. Remove both fuse holders. To do this, push and twist the knob counter-clockwise and pull the fuse holder out as illustrated in Figure 4.1.




Figure 4.1: Remove fuse holders

4. As shown in Figure 4.2, remove the old fuses from the holders and insert the new ones.




Figure 4.2: Replacing the fuse in the fuse holder

5. Ensure the fuse being installed is a **3.5 A, 250 V, 3AG Slow Blow** fuse. For example, the following fuses are acceptable replacements:
  - Digi-Key: 283-2750-ND,
  - Electrosonic: MDL-3-1/2








**Caution:** Installing the wrong fuse rating may result in damage to your amplifier.

6. Install the fuse holders back into the amplifier. Push the fuse holder into the panel and twist the knob clockwise until secure.
7. Connect the power cable to the back of the amplifier.

# 5 WIRING PROCEDURE

## 5.1 Cable Nomenclature

The cables used to connect the Quanser AMPAQ-PWM to a Quanser DAQ and experiment are shown in Table 5.1. Depending on your configuration, not all these cables are necessary.

Cable	Type	Description
 <p>(a) RCA Cable</p>	2xRCA to 2xRCA	RCA-to-RCA cables connect the AMPAQ-PWM <i>Amplifier Command</i> and <i>Current Sense</i> connectors to the DAQ. RCA-to-RCA cables are also used to connect the S1, S2, S3, and S4 Analog Sensor outputs to the DAQ. Three pairs are supplied.
 <p>(b) Motor Cable</p>	4-pin-Amphenol to 4-socket-Amphenol	This cable connects the output of the AMPAQ-PWM to the desired load.
 <p>(c) E-Stop</p>	E-Stop	The E-Stop must be connected to the AMPAQ-PWM for proper operation. The E-Stop button locks in the disabled position when pressed. To release the E-Stop, twist the red button clockwise.
 <p>(d) From Device Cable</p>	DB15 to DB15	This cable connects the AMPAQ-PWM <i>From Device</i> connector to the Shake Table II circuit board. It carries the three limit switch signals, the motor Hall effect signals, and the motor encoder signals. It also supplies the DC power required by the sensors.
 <p>(e) Encoder Cable</p>	5-pin-stereo-DIN to 5-pin-stereo-DIN	This cable carries the encoder signals between the AMPAQ-PWM <i>Encoder</i> connector and the DAQ. These signals are: +5 VDC power supply, ground, channel A, and channel B. (Channel Z is optional.)




Cable	Type	Description
 <p>(f) Analog Cable</p>	6-pin-mini-DIN to 6-pin-mini-DIN	This cable connects an external analog sensor to the AMPAQ-PWM S1, S2, S3, or S4 Analog Sensor input. The cable also supplies $\pm 12$ VDC from the AMPAQ-PWM to power the sensor.
 <p>(g) Digital I/O Cable</p>	16-pin Ribbon Cable	This cable connects the Digital I/O connector on the AMPAQ-PWM to a Q2-USB or QPIDE terminal board.
 <p>(h) Split Digital I/O Cable</p>	Split 16-pin Ribbon Cable	This cable connects the Digital I/O connector on the AMPAQ-PWM to a Q8-USB.

Table 5.1: Cables used to connect the AMPAQ-PWM to a Quanser DAQ and experiment

## 5.2 Typical Connections

Refer to the experiment-specific User Manual and Laboratory Guide for wiring instructions.

## 6 TROUBLESHOOTING

Follow the steps given below based on your issue with the AMPAQ-PWM.

### **Amplifier does not power up.**

- Make sure the power cable is firmly connected to the power connector on the back of the amplifier
- Verify that the fuse is not burnt. If the fuse is burnt, see Section 4 for fuser rating and replacement information.

### **Motor/load is not being driven.**

- Verify that the fuse is not burnt. If the fuse is burnt, see Section 4 for fuser rating and replacement information.
- If the AMPAQ-PWM is being used with a Quanser system, verify that all the connections illustrated in the User Manual for that Quanser product have been made correctly.
- If the Emergency stop switch is connected to the amplifier, make sure the red button is in the upper position to enable the amplifier. The amplifier cannot be enabled when the button is in the lower position. The *Enabled* LED on each channel should be lit. Twist to release the red button into the enabled position.

## 7 TECHNICAL SUPPORT

To obtain support from Quanser, go to <http://www.quanser.com/> and click on the Tech Support link. Fill in the form with all the requested software and hardware information as well as a description of the problem encountered. Also, make sure your e-mail address and telephone number are included. Submit the form and a technical support person will contact you.

Mix and match components and peripherals to suit your education or research needs



Quanser's range of control peripherals includes amplifiers and data acquisition boards. They can be purchased separately to control educational or research-grade plants. Mix and match these peripherals with Quanser plants and control design software to accelerate control system design and implementation.

To find the right peripherals for your teaching or research needs, please email [info@quanser.com](mailto:info@quanser.com).

©2016 Quanser Inc. All rights reserved.



[INFO@QUANSER.COM](mailto:INFO@QUANSER.COM)

+1-905-940-3575

[QUANSER.COM](http://QUANSER.COM)

Solutions for teaching and research. Made in Canada.